



1. All parts unassembled



2. Threaded rod screwed into base



3. Spring over threaded rod, on to base



4. Flange on to threaded rod, over spring



5. Washer on to threaded rod



6. Nut on to threaded rod



7. Nut tightened down, putting tension on spring