











This command us used to switch-off the power supply(main contactor) and automatically set the set value to zero (WA 000000).



